




**JANUS**  
INTERNATIONAL

PANTHEON WIRELESS KEYPAD  
INSTALLATION & USER'S MANUAL

### Box Contents



To begin use, firstly remove insulation from battery compartment. Please refer to 7. Changing Batteries instructions.

### (1) Setting Your Wireless Keypad Master PIN

**NOTE: The Master PIN MUST be reset before use.**

Step 1. Enter the factory preset default PIN followed by the PROG button.




While in programming (PROG) mode, both & are on.

Step 2. Initiate Master PIN change function by pressing the right shown buttons in sequence.



Unit beeps and & flashing, to signal for PIN input.

Step 3. Enter your New 4 to 8 digits PIN then press Enter to confirm.



4 to 8 digits

Step 5. Keypad will beep twice to signal Master PIN has been successfully changed, and will automatically exit programming mode after 20 seconds.

**IMPORTANT :** Please write down your Master PIN below and keep this document in a secure place for future reference




If Master PIN is lost and unrecoverable, the keypad is required to be returned to Janus and a reset fee is applicable.

Return Address : 135 Janus International Blvd., Temple, GA 30179


### (2) Keypad Door Operation Key Setting

**NOTE: Key setting is determined by the wiring between the PANTHEON controller and receiver. Please refer to the below wiring setups for the corresponding keypad control buttons. If the PANTHEON controller is supplied with a receiver already fitted, the receiver is pre-wired from the factory with the 3 Buttons setup.**

#### 3 Buttons UP/ STOP/ DOWN Control Wiring



#### Single Button Multi-Door Control Wiring (Max. 3 Doors)




### (3) Keypad Programming to the PANTHEON Receiver

Step 1. On the keypad, enter your PIN then press .

Step 2. On the PANTHEON receiver, press and release the LEARN button. The learn indicator will glow for 5 seconds.

Step 3. On the keypad, press and release the door operation key that will operate the door.

- For 3 Buttons UP/ STOP/ DOWN Press to program.
- For Single Button Control Referring to 2. Pantheon Receiver Wiring, press the door operation button that will operate the door i.e. or or .




PANTHEON Receiver

NOTE: To program more than one wireless keypad to the receiver, repeat the above instructions

**IMPORTANT: If a wireless keypad is lost or stolen, please refer to the receiver user's manual for procedures to delete the code.**

#### (4) Keypad Operation

Step 1. Enter PIN followed by the ENTER button.



Step 2. Press the designated keypad operation key.



✓ will remain on for 20 seconds for consecutive door operations, without re-entering the PIN.


#### (5) Optional Secondary PIN Setting

The JANUS Wireless keypad allows for up to 10 individual PIN's to be programmed (CODE 01-10), which can be used for different employees, family members or to act as a temporary PIN for house-sitters, visitors or service personnels.

Below is an example instruction to set a secondary PIN for CODE 06 slot.


NOTE: CODE 01 is the MASTER PIN.

Step 1. Enter the Master PIN followed by the PROG button.



While in programming (PROG) mode, both ⚡ & ✓ are on.

Step 2. Press ENTER then the designated code slot.




Unit beeps and ⚡ & ✓ flashing, to signal for PIN input.

For example, Code 06 slot.

NOTE: Replace 06 with other CODE slots 02-10 as required.

Step 3. Enter the 4 to 8 digits PIN for Code 06 slot then press Enter to confirm.




Step 4. Keypad will beep twice to signal PIN has been successfully set, and will automatically exit programming mode after 20 seconds.

#### (6) Deleting Secondary PIN

Below is an example instruction to delete a secondary PIN for CODE 06 slot.

Step 1. Enter the Master PIN followed by the PROG button.



While in programming (PROG) mode, both ⚡ & ✓ are on.

Step 2. Press ENTER then the designated code slot.



Unit beeps and ⚡ & ✓ flashing, to signal for PIN input.

For example, Code 06 Slot.

NOTE: Replace 06 with other CODE slots 02-10 as required.

Step 3. Press Enter to delete PIN.



Step 4. Keypad will beep twice to signal PIN has been deleted, and will automatically exit programming mode after 20 seconds.


#### (7) Changing Batteries

Step 1. Remove the battery compartment cover by sliding downwards.

Step 2. Remove the depleted batteries and dispose of it properly.

Step 3. Install 3 new AAA 1.5V alkaline or lithium batteries, note the +/- polarities indicated in the battery compartment.

Step 4. Replace the battery compartment cover by sliding upwards.




#### (8) Mounting Instructions

Mount the keypad in clear view of the door with the two screws supplied.

Push in the screw plug to conceal the top screw.

Remove batteries to affix bottom screw. Refer to 7. Changing Batteries.



#### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.