


Revisions			
Rev.	Description	Date	APRVD.
0	Released for distribution.	7/15/03	B.B.
1	REVD., CHNGD. NAME AND RMVD. MID-SPAN BRACING.	1/13/04	M.H.



**NOTES:**

- 1) FASTEN THE BOTTOM CHANNEL TO THE FLOOR USING AIR OR POWDER ACTUATED FASTENERS.
- 2) CONNECT THE TOP CHANNEL TO THE "RED IRON" BRACING USING XXX.
- 3) INSERT THE CORAWALL FLUSH WALL PANELS INTO THE TOP AND BOTTOM CHANNELS. SLIDE THE INTERLOCKING "FACES" OF THE CORAWALL FLUSH WALL UNITS UNTIL FLUSH. FASTEN ALONG THE FACE OF THE SIDES OF THE CORAWALL FLUSH WALL SECTIONS TO THE TOP CHANNEL'S OUTER LIP USING TEKS SCREWS (AS SHOWN IN THE REAR VIEW).
- 4) SECURE THE BOTTOM OF THE CORAWALL FLUSH WALL SECTIONS TO THE BOTTOM CHANNEL'S FRONT FACE USING TEKS SCREWS (AS SHOWN IN REAR VIEW).
- 5) IF INCLUDED IN PARTS GROUPING, SECURE THE MIDSPAN BRACING ACROSS THE BACK OF THE CORRUGATED WALL SECTIONS USING TEKS SCREWS (AS SHOWN IN REAR VIEW).

**Rear View**

**Flush Hallway Panel Unit**

<b>JANUS INTERNATIONAL CORPORATION</b> 134 East Luke Road Temple, Georgia 30179-4435 Phone (770) 562-2580 Fax (770) 562-2264 Web Address: WWW.JANUSINTL.COM <small>© 2002 Janus International Corporation All Rights Reserved</small>		
<b>TITLE:</b> <b>Flush Hallway Panel Unit Illustration</b>		
DESIGNED: Bert Brown	DATE: July 14, 2003	
DRAWN: Becky Nelson	DATE: July 14, 2003	
CHECKED: Morgan Hodges	DATE: July 15, 2003	
APPROVED: Bert Brown	DATE: July 15, 2003	
SIZE: <b>A</b>	DRAWING NUMBER: <b>-900-005-0006</b>	REV: <b>1</b>
SCALE: <b>1:?</b>	SHEET: <b>1</b>	OF: <b>1</b>